



Honda 2000w Generator Instructions

- Turn gas cap dial on top of unit to ON
- Turn engine dial on side of unit to ON
- Make sure choke lever on side of unit is in the FORWARD/RIGHT position
- Make sure the eco throttle switch on front of unit is OFF
- Pull the starter pull cord on side of unit until it starts
- ***Once it is running, flip choke lever on side of unit to the opposite (LEFT) position to keep generator running***

NOTE:

Never allow unit to fall over on its side and spill. This will damage the generator and require an additional repair/cleaning fee. Always make sure unit is secure during transport.